

1 Key Combinations



File

New Design Project	"CTRL" + "N"
Open	"CTRL" + "O"
Save	"CTRL" + "S"
Save As	F12


Editieren

Copy	"CTRL" + "C"
Paste	"CTRL" + "V"
Select All	"CTRL" + "A"
Go to Selection	"CTRL" + "B"
Cancel selection	"CTRL" + "D"
Cut	"CTRL" + "X"
Redo	"CTRL" + "Y"
Undo	"CTRL" + "Z"
Selection of a needle action or of a module	F5
Selection of pattern color	F6
Selection of the needle action or module and of the pattern color	"F5 " + "F6"
Selection of shape attributes	F7
Selection of all visible properties	F8
Canceling the selection at the cursor	ESC
Replace All Matches (with Find and Replace)	"ALT" + "A"
Replace and Find Next (with Find and Replace)	"ALT" + "R"
Canceling the selection at the cursor	ESC


View

Open Knit Explorer	F3
--------------------	----


Open Find and Replace dialog box	"CTRL" + "F"
Open Create Jacquard dialog box	"CTRL" + "J"
Open Fabric View	F
Scroll to the first needle position	HOME
Scroll to top	"CTRL" + "HOME"
Scroll to the last needle position	END
Scroll to bottom	"CTRL" + "END"
Scroll up a single line	WHEELUP
Scroll down a single line	WHEELDOWN
Toggle ToolTip on stitch information at the cursor position.	"," (COMMA)



Toggle ToolTip on current drawing tool at the "." (POINT) cursor position.



Toggle ToolTip on knitting information at the "-" (MINUS) cursor position



Zoom

Synchronization of the Zoom views in all windows	X
Switch zoom level	Z

Larger zoom level	NUM "+"
Smaller zoom level	NUM "-"
Open Help Topics	F1

"Drawing Tools" in "CREATE"

Line	B
Echo Mode	E
Magic Wand (all directions)	J
Magic Wand (to the left and right)	L
Move	M
Rectangle	N
Rotate	R
Edit Shape	Y
Pencil	V
Fill Selection	"ALT" + "F5"

1 Tastenkombinationen



Datei


Neues Design-Projekt	"STRG" + "N"
Öffnen	"STRG" + "O"
Speichern	"STRG" + "S"
Speichern unter	F12

Editieren


Kopieren	"STRG" + "C"
Einfügen	"STRG" + "V"
Alles auswählen	"STRG" + "A"
Zur Selektion gehen	"STRG" + "B"
Auswahl aufheben	"STRG" + "D"
Ausschneiden	"STRG" + "X"
Wiederherstellen	"STRG" + "Y"
Rückgängig	"STRG" + "Z"
Auswahl einer Nadelaktion oder Moduls	F5
Auswahl einer Musterfarbe	F6
Auswahl der Nadelaktion oder Moduls und der Musterfarbe	"F5 " + "F6"
Auswahl der Schnittattribute	F7
Auswahl aller sichtbaren Eigenschaften	F8
Aufheben der Cursor-Auswahl	ESC
Alle Treffer ersetzen (bei Suchen und Ersetzen)	"ALT" + "A"
Ersetzen und Weitersuchen (bei Suchen und Ersetzen)	"ALT" + "R"
Aufheben der Cursor-Auswahl	ESC

Ansicht


Knit Explorer öffnen	F3
Dialog Suchen und Ersetzen öffnen	"STRG" + "F"
Dialog Jacquard erzeugen öffnen	"STRG" + "J"
Gestrickansicht öffnen	F
An die erste Nadel rollen	POS1
Ganz nach oben rollen	"STRG" + "POS1"
An die letzte Nadel rollen	ENDE
Ganz nach unten rollen	"STRG" + "ENDE"
Um eine Zeile nach oben rollen	RAD VOR
Um eine Zeile nach unten rollen	RAD ZURÜCK
QuickInfo zur Mascheninformation der Cursorposition ein- und ausschalten.	"," (KOMMA)



QuickInfo des gerade verwendeten Zeichenwerkzeuges der Cursorposition ein- und ausschalten.	"." (PUNKT)
---	-------------



QuickInfo der Strickinformation der Cursorposition ein- und ausschalten.	"-" (MINUS)
--	-------------



Zoom

Synchronisation der Zoom-Ansichten in allen Fenstern	X
Umschalten der Zoom-Stufe	Z
Größere Zoomstufe	NUM "+"
Kleinere Zoomstufe	NUM "-"
Hilfeseiten öffnen	F1

"Zeichenwerkzeuge" in "CREATE DESIGN "

Linie	B
Echo Modus	E
Zauberstab (alle Richtungen)	J
Zauberstab (nach links und rechts)	L
Verschieben	M
Rechteck	N
Drehen	R
Schnitt bearbeiten	Y
Freihandlinie	V
Selektion füllen	"ALT" + "F5"